

CLUTCH PEDAL POSITION (CPP) SWITCH FUNCTION [LF]

B3E014018990T01

- This switch determines whether the engine is under a load condition (condition in which the engine output is transmitted to the powertrain) or under a no-load condition (condition in which the engine output is not transmitted to the powertrain).
- Detects the clutch engagement condition.