


FRONT SUSPENSION LOCATION INDEX

B3E021301015W01



B3E0213W032

1	Front shock absorber and coil spring (See FRONT SHOCK ABSORBER AND COIL SPRING REMOVAL/INSTALLATION.)
2	Front shock absorber (See FRONT SHOCK ABSORBER INSPECTION.) (See FRONT SHOCK ABSORBER DISPOSAL.)
3	Front lower arm (See FRONT LOWER ARM REMOVAL/INSTALLATION.) (See FRONT LOWER ARM INSPECTION.)
4	Front stabilizer (See FRONT STABILIZER REMOVAL/INSTALLATION.)
5	Stabilizer control link (See STABILIZER CONTROL LINK INSPECTION.)
6	Front crossmember (See FRONT CROSSMEMBER REMOVAL/INSTALLATION.)