

DTC B1342, C1267 [ABS]

B3E040243000W04

DTC	B1342, C1267	ABS HU/CM (internal malfunction)
DETECTION CONDITION	• The ABS HU/CM on-board diagnostic function detects control module internal malfunction.	
POSSIBLE CAUSE	• ABS HU/CM internal malfunction	

Diagnostic procedure

STEP	INSPECTION		ACTION
1	VERIFY NO ABS HU/CM MALFUNCTION <ul style="list-style-type: none"> • Clear the DTCs from the memory. (See Clearing DTCs Procedures.) • Start the engine and drive the vehicle at 10km/h {6.2 mph} or more. • Are the same DTCs present? 	Yes	Replace the ABS HU/CM, then go to the next step. (See ABS HU/CM REMOVAL/INSTALLATION .)
		No	Go to the next step.
2	VERIFY THAT NO OTHER DTCS ARE PRESENT <ul style="list-style-type: none"> • Are any other DTCs output? 	Yes	Go to the applicable DTC inspection. (See DTC Table .)
		No	DTC troubleshooting completed.