

NO.2 ABS WARNING LIGHT DOES NOT ILLUMINATE WHEN THE IGNITION SWITCH IS TURNED TO THE ON POSITION

B3E040367650W06

2	ABS warning light does not illuminate when the ignition switch is turned to the ON position.
[TROUBLESHOOTING HINTS]	
• Instrument cluster malfunction	