

NO.3 BRAKE SYSTEM WARNING LIGHT DOES NOT ILLUMINATE WHEN THE IGNITION SWITCH IS TURNED TO THE ON POSITION

B3E040367650W07

3	BRAKE system warning light does not illuminate when the ignition switch is turned to the ON position.
[TROUBLESHOOTING HINTS]	
• Instrument cluster malfunction	