


PARKING BRAKE LEVER ADJUSTMENT

B3E041244300W05

1. Pump the brake pedal a few times.
2. Remove the service hole cover of the rear console.



3. Turn the adjusting nut and adjust the parking brake lever.
4. After adjustment, pull the parking brake lever one notch and verify that the parking brake warning light illuminates.
5. Verify that the rear brakes do not drag.