


PARKING BRAKE SWITCH INSPECTION

B3E041266450W01

1. Disconnect the parking brake switch connector.
2. Verify that the continuity is as indicated in the table.



B3E0412W006

- If not as indicated in the table, replace the parking brake lever.

Condition	Terminal	
	A	Body ground
Parking brake lever pulled	○	○
Parking brake lever released		

CHU0412W003