

FRONT ABS WHEEL-SPEED SENSOR INSPECTION

B3E041543720W02

1. Inspect the front ABS wheel-speed sensor in the same order of vehicles with ABS. (See [FRONT ABS WHEEL-SPEED SENSOR INSPECTION](#).)