

TRANSMISSION/TRANSAXLE ABBREVIATIONS

B3E050001030T01

ATF	Automatic Transaxle Fluid
ATX	Automatic Transaxle
B+	Battery Positive Voltage
CCM	Comprehensive Component Monitor
CPU	Central Processing Unit
DC	Drive Cycle
DLC	Data Link Connector
DTC	Diagnostic Trouble Code
EC-AT	Electronically Controlled Automatic Transaxle
GND	Ground
MIL	Malfunction Indicator Lamp
MTX	Manual Transaxle
O/D	Overdrive
OBD	On-board Diagnostic
PCM	Powertrain Control Module
PID	Parameter Identification
TCC	Torque Converter Clutch
TFT	Transaxle Fluid Temperature
TP	Throttle Position
TR	Transaxle Range
VSS	Vehicle Speed Sensor
1GR	First Gear
2GR	Second Gear
3GR	Third Gear
4GR	Fourth Gear
5GR	Fifth Gear