

GENERAL PROCEDURES (CLUTCH)

B3E051016003W02

Note

- A common reserve tank is used for the clutch and brake system fluid.

Caution

- If clutch pipes have been disconnected any time during the procedure, add clutch fluid (brake fluid), bleed the air, and inspect for leakage after the procedure has been completed.