


CLUTCH FLUID INSPECTION

B3E051016010W01

Note

- A common reserve tank is used for the clutch and brake system fluid.
- The fluid in the reserve tank must be maintained between the MIN/MAX level during replacement.

L.H.D.



R.H.D.

