

INPUT/OUTPUT SIGNAL AND RELATED CONTROLS

B3E051701030T17

Component	Control item								
	Line pressure control	Shift control	Clutch pressure direct control (Direct electric shift control)	Feedback control	Engine-transaxle total control	Torque converter clutch control	Slope mode control	On-board diagnostic function	Manual mode shift control
Input									
M range switch		X	X						X
Up switch		X	X						X
Down switch		X	X						X
TR switch	X	X	X						
TP sensor	X	X	X			X		X	
Input/turbine speed sensor	X	O	X	X		X		X	
VSS	X	X	X			X	X	X	
Brake switch							X		
TFT sensor	X	X	X	X		X		X	
ECT sensor						X		X	
CKP sensor	X		X		X	X		X	
MAF sensor	X		X	X	X		X	X	
Output									
Pressure control solenoid	X							X	
Shift solenoid A		X	X	X		X	X	X	
Shift solenoid B		X	X	X				X	
Shift solenoid C		X	X	X				X	
Shift solenoid D		X					X	X	
Shift solenoid E		X				X	X	X	
AT warning light		X						X	
Speedometer signal									

X : Available

O : Back up