

PCM INSPECTION

B3E051718901W01

1. Inspect the PCM.

(See [PCM INSPECTION \[ZJ, Z6\]](#).)

(See [PCM INSPECTION \[LF\]](#).)