


## SELECTOR LEVER DISASSEMBLY/ASSEMBLY

B3E051846102W05

1. Disassemble in the order indicated in the table.
2. Assemble in the reverse order of disassembly.



B3E0518W011

1	Selector lever knob
2	Indicator panel
3	Selector lever component