

## DTC B2141, B2477

B3E060201038W07

<b>DTC</b>	<b>B2141, B2477</b>	<b>EHPAS control module configuration</b>
<b>DETECTION CONDITION</b>	• Configuration setting failure is detected.	
<b>POSSIBLE CAUSE</b>	• Module configuration procedure was not completed properly.	

### Diagnostic procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY CONFIGURATION</b> • Has the EHPAS control module configuration been performed?	Yes	Go to the next step.
		No	Perform configuration using the WDS or equivalent. (See <a href="#">ELECTRO HYDRAULIC POWER ASSIST STEERING (EHPAS) CONTROL MODULE CONFIGURATION.</a> )
2	<b>VERIFY THAT THE SAME DTC IS NOT PRESENT</b> • Clear the DTC from the memory. (See <a href="#">Clearing DTCs Procedure.</a> ) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the EHPAS control module. (See <a href="#">ELECTRIC POWER STEERING OIL PUMP (LF) REMOVAL/INSTALLATION.</a> )
		No	Go to the next step.
3	<b>VERIFY THAT NO OTHER DTCs ARE PRESENT</b> • Are any other DTCs output?	Yes	Go to the applicable DTC inspection. (See <a href="#">DTC Table.</a> )
		No	DTC troubleshooting completed.