

P/S ANGLE SENSOR OUTLINE

B3E061443720T01

Function

- The P/S angle sensor uses a hall sensor system and transmits the steering wheel turning status to the EHPAS control module.