


ELECTRO HYDRAULIC POWER ASSIST STEERING (EHPAS) WIRING DIAGRAM

B3E061467880T02



B3E0602T006

1	Battery
2	P/ST 80 A fuse
3	Ignition switch
4	IGNITION 20 A fuse
5	P/ST IG 10 A fuse
6	P/S angle sensor
7	EHPAS control module
8	CAN driver
9	CAN_L
10	CAN_H