


FAN SWITCH INSPECTION

B3E074061060W03

1. Remove the climate control unit.
2. Verify that the continuity between the fan switch terminals is as indicated in the table.
 - If there is any malfunction, replace the fan switch.



B3E0740W060

○ — ○ : Continuity

Switch position	Terminal					
	A	B	C	D	E	F
0						
1	○	—	○	—	○	
2	○		○			○
3	○	—	○	○		
4	○	○	○			

B3E0740W061