


# AIRFLOW TEMPERATURE CONTROL SYSTEM DIAGRAM

B3E074061190T04



B3E0740T412

1	Set temperature
2	Solar radiation amount
3	Ambient temperature
4	Evaporator temperature
5	Cabin temperature
6	Airflow mode
7	A/C compressor control condition
8	Signal
9	Climate control unit
10	Output
11	Feedback
12	Air mix actuator
13	Operation
14	Air mix door
15	Airflow temperature change