


AIRFLOW VOLUME CONTROL SYSTEM DIAGRAM

B3E074061190T07



B3E0740T042

1	Fan switch
2	Set temperature
3	Airflow mode
4	Ambient temperature
5	Cabin temperature
6	Solar radiation amount
7	Engine coolant temperature
8	ECT sensor
9	Signal
10	Climate control unit
11	Output
12	Feedback
13	Power MOS FET
14	Operation
15	Blower motor
16	Airflow volume change