


AIR INTAKE CONTROL SYSTEM DIAGRAM

B3E074061190T13



B3E0740T032

1	REC/FRESH switch
2	A/C compressor control condition
3	Defroster switch
4	Solar radiation amount
5	Ambient temperature
6	Cabin temperature
7	Signal
8	Climate control unit
9	Output
10	Air intake actuator
11	Operation
12	Air intake door
13	Air intake mode change