

CLEARING DTC

B3E080201046W04

1. After repairs have been made, retrieve DTCs.
2. Using the WDS or equivalent, clear DTCs from the memory.
3. Perform the DTC inspection again and verify that no DTC is displayed.