

## DTC B1921

B3E080201046W17

DTC B1921	Air bag diagnostic monitor ground circuit open
<b>DETECTION CONDITION</b>	<p><b>Warning</b></p> <ul style="list-style-type: none"><li>• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.</li><li>• SAS control module configuration has not been performed.</li></ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• No SAS control module configuration</li><li>• SAS control module malfunction</li></ul>

### Diagnostic procedure

STEP	INSPECTION		ACTION
1	<b>INSPECT SAS CONTROL MODULE</b> <ul style="list-style-type: none"><li>• Using the WDS or equivalent, perform SAS control module configuration.</li><li>• Is DTC B1921 indicated?</li></ul>	Yes	Replace the SAS control module. (See <a href="#">SAS CONTROL MODULE REMOVAL/INSTALLATION</a> .)
		No	DTC troubleshooting completed.