

AIR BAG SYSTEM

B3E080301046W01

Troubleshooting Index

- Use the chart below to verify the symptoms of the trouble in order to diagnose the appropriate area.

No.	Troubleshooting item	Description	Page
1	Air bag system warning light does not illuminate.	Malfunction in air bag system warning light circuit	(See NO.1 AIR BAG SYSTEM WARNING LIGHT DOES NOT ILLUMINATE.)
2	Air bag system warning light illuminates constantly.	Malfunction in air bag system warning light circuit	(See NO.2 AIR BAG SYSTEM WARNING LIGHT ILLUMINATES CONSTANTLY.)