

NO.1 AIR BAG SYSTEM WARNING LIGHT DOES NOT ILLUMINATE

B3E080301046W02

1	Air bag system warning light does not illuminate.
DETECTION CONDITION	Malfunction in air bag system warning light circuit
POSSIBLE CAUSE	<ul style="list-style-type: none"> • SAS control module malfunction • Instrument cluster malfunction • CAN communication network malfunction

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	CONFIRM DTC U0151 USING WDS OR EQUIVALENT <ul style="list-style-type: none"> • Retrieve DTC from the SAS control module and instrument cluster. • Is DTC U0151 retrieved? 	Yes Network communication for related systems has a malfunction. Repair or replace if necessary.
		No Inspect the instrument cluster. If the instrument cluster is normal, go to the next step. If the instrument cluster has a malfunction, replace the instrument cluster.
2	CONFIRM DTC B2477 FOR INSTRUMENT CLUSTER USING WDS OR EQUIVALENT <ul style="list-style-type: none"> • Is DTC B2477 retrieved? 	Yes Re-configure the instrument cluster.
		No Replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION.)