

SIDE AIR BAG MODULE FUNCTION

B3E081000147T01

- During a collision to the side of the vehicle, the air bag operates (deploys) after receiving an operation signal from the SAS control module, defusing impact to the chest area of the driver and front passenger.