


# AIR BAG SYSTEM WIRING DIAGRAM

B3E081001046T03



B3E08 10T350

1	SAS control module
2	Crash zone sensor
3	Twisted pair
4	PAD indicator
5	PAD switch
6	PASS AIRBAG ON
7	PASS AIRBAG OFF
8	Driver-side buckle switch

9	Driver-side side air bag sensor
10	Passenger-side side air bag sensor
11	Can system-related module
12	Instrument cluster
13	Clock spring
14	Driver-side air bag module
15	Inflator No.1
16	Inflator No.2
17	Passenger-side air bag module
18	Driver-side pre-tensioner front buckle
19	Driver-side curtain air bag module
20	Driver-side side air bag module
21	Passenger-side pre-tensioner front buckle
22	Passenger-side curtain air bag module
23	Passenger-side side air bag module