

DTC B2897

B3E090201072W46

DTC B2897	Auto light relay circuit failure
DETECTION CONDITION	Short to power supply in PJB internal circuit between microcomputer and headlight LO relay
POSSIBLE CAUSE	• PJB malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	INSPECT DTC <ul style="list-style-type: none">• Clear the DTC from the PJB memory using the WDS or equivalent.• Perform the self-test. (See PJB SELF-TEST.)• Is the same DTC present?	Yes	Replace the PJB. (See PASSENGER JUNCTION BOX (PJB) REMOVAL/INSTALLATION.)
		No	DTC troubleshooting completed.