

# SECURITY LIGHT 23, DTC B2139/P1260

B3E090201077W15

<b>SECURITY LIGHT: 23</b>	ID number data in the PCM and the instrument cluster do not match.
<b>DTC: B2139/P1260</b>	
<b>DETECTION CONDITION</b>	• ID number data in the instrument cluster and the PCM are different.
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>• Necessary procedures were not performed using the WDS or equivalent after replacing the PCM.</li> <li>• Instrument cluster malfunction</li> <li>• PCM malfunction</li> </ul>

## Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY DTC</b> <ul style="list-style-type: none"> <li>• Are either U1900 or U0073, or both, displayed, by either the instrument cluster or the PCM, or both?</li> </ul>	Yes	Perform troubleshooting according to the corresponding DTC inspection. (See <a href="#">DTC U0073, U0516, U1900, U2516.</a> )
		No	Go to the next step.
2	<b>EXAMINE INSTRUMENT CLUSTER AND PCM</b> <ul style="list-style-type: none"> <li>• Perform procedures for when replacing the PCM only. (See <a href="#">IMMOBILIZER SYSTEM COMPONENT REPLACEMENT/KEY ADDITION AND CLEARING.</a>)</li> <li>• Using the registered key, turn the ignition switch to the ON position.</li> <li>• Is the DTC displayed?</li> </ul> <p>- Security light: 23 - WDS or equivalent: B2139/P1260</p>	Yes	<ul style="list-style-type: none"> <li>• Replace the instrument cluster and perform the resetting procedure for the immobilizer system when replacing the instrument cluster. (See <a href="#">INSTRUMENT CLUSTER REMOVAL/INSTALLATION.</a>)</li> <li>(See <a href="#">IMMOBILIZER SYSTEM COMPONENT REPLACEMENT/KEY ADDITION AND CLEARING.</a>)</li> <li>• Go to the next step.</li> </ul>
		No	DTC troubleshooting completed.
3	<b>VERIFY DTC</b> <ul style="list-style-type: none"> <li>• Is the DTC displayed again?</li> </ul> <p>- Security light: 23 - WDS or equivalent: B2139/P1260</p>	Yes	<ul style="list-style-type: none"> <li>• Replace the PCM and perform the resetting procedure for the immobilizer system when replacing the PCM. (See <a href="#">PCM REMOVAL/INSTALLATION [ZJ, Z6].</a>)</li> <li>(See <a href="#">PCM REMOVAL/INSTALLATION [LF].</a>)</li> <li>(See <a href="#">IMMOBILIZER SYSTEM COMPONENT REPLACEMENT/KEY ADDITION AND CLEARING.</a>)</li> </ul>
		No	DTC troubleshooting completed.