

DTC TABLE [MULTIPLEX COMMUNICATION SYSTEM]

B3E090255430W02

DTC	Malfunction location	DTC output module	Page
U0073	CAN system communication error	<ul style="list-style-type: none"> • PCM • EHPAS control module • Instrument cluster 	(See DTC U0073, U2012.)
		SAS control module	(See DTC U0073, U0516, U1900, U2516.)
U0100	Communication error to PCM	<ul style="list-style-type: none"> • EHPAS control module • Instrument cluster 	(See PROCEDURES FOR DETERMINING THE LOCATION OF A MALFUNCTION.)
U0121	Communication error to DSC HU/CM or ABS HU/CM	<ul style="list-style-type: none"> • PCM • Instrument cluster 	
U0131	Communication error to EHPAS control module	Instrument cluster	
U0140	Communication error to PJB	<ul style="list-style-type: none"> • Instrument cluster • Climate control unit 	
U0151	Communication error to SAS control module	Instrument cluster	
U0155	Communication error to instrument cluster	<ul style="list-style-type: none"> • PCM • Climate control unit 	
U0184	Communication error to audio unit (base module)	<ul style="list-style-type: none"> • Instrument cluster • Climate control unit 	
U0516	CAN system communication error	Climate control unit	(See DTC U0073, U0516, U1900, U2516.)
U1900	Communication error to PCM	<ul style="list-style-type: none"> • ABS HU/CM (with ABS) • DSC HU/CM (with DSC) 	(See PROCEDURES FOR DETERMINING THE LOCATION OF A MALFUNCTION.)
	Communication error to instrument cluster	SAS control module	
	CAN system communication error Abnormal message from other modules	PJB	(See PROCEDURES FOR DETERMINING THE LOCATION OF A MALFUNCTION.) (See DTC U0073, U0516, U1900, U2516.)
U2012	CAN system communication error	<ul style="list-style-type: none"> • ABS HU/CM (with ABS) • DSC HU/CM (with DSC) 	(See DTC U0073, U2012.)
U2023	Abnormal message from PCM	EHPAS control module	(See PROCEDURES FOR DETERMINING THE LOCATION OF A MALFUNCTION.)
U2202	Communication error to PCM	DSC HU/CM (with	(See PROCEDURES FOR DETERMINING

		DSC)	THE LOCATION OF A MALFUNCTION.)
U2516	CAN system communication error	Instrument cluster	(See DTC U0073, U0516, U1900, U2516.)
U2523	Communication error to PCM	<ul style="list-style-type: none"> • ABS HU/CM (with ABS) • DSC HU/CM (with DSC) 	(See PROCEDURES FOR DETERMINING THE LOCATION OF A MALFUNCTION.)