

DTC B1342 [INSTRUMENT CLUSTER]

B3E090255430W08

DTC B1342	• Instrument cluster malfunction
DETECTION CONDITION	• Malfunction in the instrument cluster internal circuit
POSSIBLE CAUSE	• Instrument cluster malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	INSPECT INSTRUMENT CLUSTER <ul style="list-style-type: none">• Clear the DTC from the memory.• Turn the ignition switch to the LOCK position.• Turn the ignition switch to the ON position.• Is B1342 displayed?	Yes	Replace the instrument cluster.
		No	DTC troubleshooting completed.