

DTC TABLE [AUDIO SYSTEM]

B3E090266900W04

Screen display		System malfunction location
DTC (When starting on-board diagnostic test function)	Error message (When error is found)	
09: Er22	-	Base unit (peripheral circuit for tuner)
09: Er20	-	Power supply circuit to base unit
00: Er10	-	Cassette deck communication circuit system
03: Er10	-	CD player communication circuit system
05: Er10	-	CD changer (external) communication circuit system
06: Er10	-	CD changer (upper module) communication circuit system
07: Er10	-	MD player communication circuit system
03: Er01	-	CD player system
03: Er02	CHECK CD	CD player system
03: Er07	CHECK CD	CD player system
00: Er01	-	Cassette deck system
00: Er03	-	Cassette deck system
00: Er04	CHECK TAPE	Cassette tape system
05: Er01	-	CD changer (external) system
05: Er07	CHECK CD	CD changer (external) system
06: Er01	-	CD changer (upper module) system
06: Er02	CHECK CD	CD changer (upper module) system
06: Er07	CHECK CD	CD changer (upper module) system
07: Er01	-	MD player system
07: Er02	CHECK MD	MD player system
07: Er07	CHECK MD	MD player system
07: Er08	CHECK MD	MD system
10: Er01	-	MP3 applicable CD player system
10: Er02	CHECK CD	MP3 applicable CD player system
no Er	-	No DTCs stored