

## DTC 07:ER10

B3E090266900W10

<b>DTC 07:Er10</b>	MD player-base unit communication line
<b>DETECTION CONDITION</b>	• Base unit detects communication error with MD player.
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>• Malfunction of connectors between base unit and MD player</li> <li>• MD player malfunction</li> <li>• Base unit malfunction</li> </ul>

### Diagnostic procedure

STEP	INSPECTION		ACTION
1	Remove the MD player and inspect the connector condition (bent pins, poor female terminal connection, trapped foreign material). Is the connector normal?	Yes	Go to the next step.
		No	Repair the connector and go to the next step.
2	Assemble the MD player to the base unit and verify assembly condition. Is assembly condition normal?	Yes	Go to the next step.
		No	Repair the assembly condition and go to the next step.
3	Clear the DTC, turn the ignition switch to the ON position and then hold for <b>3 s or more</b> . Is DTC 07: Er10 displayed?	Yes	Replace the base unit and MD player.
		No	DTC troubleshooting completed.