

DTC 00:ER01

B3E090266900W14

DTC 00:Er01	Cassette deck
DETECTION CONDITION	<ul style="list-style-type: none"> • Cassette deck cannot implement insert and eject commands.
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Defective cassette tape (deformation, broken, or foreign material stuck/attached) • Cassette deck malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	Can cassette tape be ejected?	Yes
		No
2	Verify condition of the cassette tape when the error occurs. Is the cassette tape normal?	Yes
		No
3	Clear the DTC. Insert then eject a normal cassette tape. Is DTC 00: Er01 displayed?	Yes
		No