

DTC 00:ER03

B3E090266900W15

DTC 00:Er03	Cassette deck
DETECTION CONDITION	• Base unit detects that reel built into cassette deck does not operate.
POSSIBLE CAUSE	• Defective cassette tape (tape slack, pinched tape in internal cassette deck) • Cassette deck malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	Verify condition of the cassette tape when the error occurs. Is the cassette tape normal?	Yes	Go to the next step.
		No	Repair (tighten slack, clear pinched tape inside cassette deck) or replace the cassette tape, and go to the next step.
2	Clear the DTC, and then insert a normal cassette tape. Play the cassette tape for 20 s or more . Is DTC 00: Er03 displayed?	Yes	Replace the cassette deck.
		No	DTC troubleshooting completed.