

DTC 06:ER01

B3E090266900W17

DTC 06:Er01	CD changer (upper module)
DETECTION CONDITION	<ul style="list-style-type: none"> CD changer (upper module) cannot implement insert, eject, and disc change commands.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Defective CD (broken or foreign material stuck/attached) CD changer (upper module) malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	Can CD be ejected?	Yes	Go to the next step.
		No	Replace the CD changer (upper module).
2	Verify the condition of the CD when the error occurs. Is the CD normal?	Yes	Go to the next step.
		No	Repair (remove foreign material) or replace the CD, and go to the next step.
3	Clear the DTC. Insert then eject a normal CD. Is DTC 06: Er01 displayed?	Yes	Replace the CD changer (upper module).
		No	DTC troubleshooting completed.