

DTC 07:ER02

B3E090266900W21

DTC 07:Er02	MD player
DETECTION CONDITION	<p>Note</p> <ul style="list-style-type: none"> When error occurs, error message "CHECK MD" is displayed in the LCD. Cannot play MD normally or change tracks.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Defective MD (scratches or dirt) MD player malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION	
1	Play the MD and change tracks. Can tracks be changed?	Yes	Go to Step 3.
		No	Cannot change to specific tracks. Go to the next step.
			Cannot change to any track. Change the MD and try to change tracks again. • If the function is normal, go to Step 3. • If the function is not normal, replace the MD player.
2	Verify the condition of the MD when the error occurs. Is the MD normal?	Yes	Go to the next step.
		No	Repair (remove foreign material, clean) or replace the MD, and go to the next step.
3	Clear the DTC. Play the MD and change tracks. Is DTC 07: Er02 displayed?	Yes	Replace the MD player.
		No	DTC troubleshooting completed.