

FOREWORD

B3E090366900W01

- Refer to section 00 and thoroughly read and understand the basic flow of troubleshooting in order to properly perform the procedures.
- For the steps that have an asterisk (*), inspect the connector/terminal connection for continuity and damage. If the connection is poor, reconnect it, or repair or replace the appropriate parts if necessary.