

# TROUBLESHOOTING INDEX

---

B3E090366900W02

- To diagnose the appropriate area, use the chart below to verify the symptoms.

No.	TROUBLESHOOTING ITEM	DESCRIPTION	PAGE
1	ALC (automatic level control) do not operate. (ABS HU/CM operates normally.)	• Malfunction in vehicle speed signal line audio unit.	(See <a href="#">NO.1 ALC (AUTOMATIC LEVEL CONTROL) DO NOT OPERATE. (ABS HU/CM OPERATES NORMALLY.)</a> )