


COWL PANEL REMOVAL/INSTALLATION

B3E091053580W01

1. Remove the windshield wiper arm and blade. (See [WINDSHIELD WIPER ARM AND BLADE REMOVAL/INSTALLATION](#).)
2. Remove the cowl grille. (See [COWL GRILLE REMOVAL/INSTALLATION](#).)
3. Remove the bolts, then remove the cowl panel.



4. Install in the reverse order of removal.