

# LIFTGATE STAY DAMPER DISPOSAL

---

B3E091162010W03

1. Referring to procedures for trunk lid stay damper disposal, dispose of the liftgate stay damper. (See [TRUNK LID STAY DAMPER DISPOSAL](#).)