

REGULATOR HANDLE REMOVAL

B3E091258580W01

1. Using a cloth, remove the regulator handle installation clip and remove the regulator handle.

