


THEFT-DETERRENT SYSTEM WIRING DIAGRAM


B3E091450000T03



B3E09 14T002

1	Door lock-link switch
2	Door key cylinder switch
3	Trunk lid key cylinder push switch
4	Trunk lid key cylinder switch
5	Keyless control module
6	Door lock relay
7	With double lock function

8	Double lock relay
9	Door unlock relay
10	Trunk lid unlock relay
11	Front door lock actuator (driver's side)
12	Front door lock actuator (passenger's side)
13	Rear door lock actuator (LH)
14	Rear door lock actuator (RH)
15	Liftgate lock actuator
16	Trunk lid opener
17	Microcomputer



B3E09 14T001

1	Trunk compartment light
2	Trunk lid latch switch
3	Cargo compartment light
4	Liftgate latch switch
5	Bonnet latch switch

6	Front door latch switch (LH)
7	Front door latch switch (RH)
8	Rear door latch switch (LH)
9	Rear door latch switch (RH)
10	Front turn light (LH)
11	Side turn light (LH)
12	Front turn light (RH)
13	Side turn light (RH)
14	Rear turn light (LH)
15	Rear turn light (RH)
16	Instrument cluster
17	Intruder sensor
18	Theft-deterrent siren
19	Microcomputer