

SUNROOF SWITCH REMOVAL/INSTALLATION

B3E091566560W01

Note

- The sunroof switch and the map light are a single unit.

1. Disconnect the negative battery cable.
2. Remove the map light from the headliner. (See [MAP LIGHT REMOVAL/INSTALLATION.](#))
3. Install in the reverse order of removal.