

# REAR DRAIN HOSE INSTALLATION

---

B3E091569922W02

## Caution

- If the rear drain hose is pinched or bent at any point, the water in the hose may not drain and could leak inside the vehicle. During and after installation of the trims and headliner, always make sure there is no interference with the rear drain hose. Correct any abnormality if found.

1. Apply soapy water to the part of the sunroof frame where the rear drain hose is inserted.
2. Insert the rear drain hose end into the sunroof frame.
3. Install the rear drain hose to the clips parallel to the pillar and free of looseness.
4. Insert the rear drain hose grommet into the hole of the inner rear pillar.
5. Install the following parts:
  - (1) Headliner (See [HEADLINER REMOVAL/INSTALLATION.](#))
  - (2) Assist handle (See [ASSIST HANDLE REMOVAL/INSTALLATION.](#))
  - (3) Sunvisor (See [SUNVISOR REMOVAL/INSTALLATION.](#))
  - (4) Interior light (See [INTERIOR LIGHT REMOVAL/INSTALLATION.](#))
  - (5) Map light (See [MAP LIGHT REMOVAL/INSTALLATION.](#))
  - (6) C-pillar trim (See [C-PILLAR TRIM REMOVAL/INSTALLATION.](#))
  - (7) Trunk side trim (See [TRUNK SIDE TRIM REMOVAL/INSTALLATION.](#))
  - (8) Trunk side upper trim (5HB) (See [TRUNK SIDE UPPER TRIM REMOVAL/INSTALLATION.](#))
  - (9) Trunk end trim (See [TRUNK END TRIM REMOVAL/INSTALLATION.](#))
  - (10) Tire house trim (See [TIRE HOUSE TRIM REMOVAL/INSTALLATION.](#))
  - (11) Rear seat (See [REAR SEAT REMOVAL/INSTALLATION.](#))
  - (12) B-pillar upper trim (See [B-PILLAR UPPER TRIM REMOVAL/INSTALLATION.](#))
  - (13) B-pillar lower trim (See [B-PILLAR LOWER TRIM REMOVAL/INSTALLATION.](#))
  - (14) Rear scuff plate (See [REAR SCUFF PLATE REMOVAL/INSTALLATION.](#))
  - (15) Front scuff plate (See [FRONT SCUFF PLATE REMOVAL/INSTALLATION.](#))
  - (16) Upper anchor of the front seat belt (See [FRONT SEAT BELT REMOVAL/INSTALLATION.](#))
  - (17) A-pillar trim (See [A-PILLAR TRIM REMOVAL/INSTALLATION.](#))
  - (18) Console (4SD) (See [CONSOLE REMOVAL/INSTALLATION.](#))