


COWL GRILLE REMOVAL/INSTALLATION

B3E091650780W01

1. Remove the windshield wiper arm and blade. (See [WINDSHIELD WIPER ARM AND BLADE REMOVAL/INSTALLATION](#).)
2. Using a small flathead screwdriver, remove the caps.
3. Remove the screws.



4. Remove the weatherstrip.
5. Move the cowl grille in the direction indicated by the arrow and disengage tabs A from the windshield.
6. Remove the cowl grille.
7. Install in the reverse order of removal.