


## DOOR SASH FILM REMOVAL

---

B3E091650810W01

1. Partially peel back the glass run channel.
2. Warm up the door sash film using a hot air blower.
3. Peel off the door sash film by pulling outward from one end.



### Note

- Be sure to remove the door sash film slowly, because it can easily tear.