


CONSOLE DISASSEMBLY/ASSEMBLY

B3E091764271W02

1. Disassemble in the order indicated in the table.



B3E0917W 106

1	Cover
2	Rear ashtray
3	Console panel
4	Plate
5	Rear console box
6	Console lid
7	Console

2. Assemble in the reverse order of disassembly.