


## SIDE WALL REMOVAL/INSTALLATION

---

B3E091768420W01

1. Remove the fastener.



2. Detach the tab and remove the side wall.
3. Install in the reverse order of removal.