



SUNVISOR REMOVAL/INSTALLATION

B3E091769250W01

1. Remove the screw, then remove the sunvisor.



2. Press the center adapter tabs in the directions of the arrows using two tape-wrapped flathead screwdrivers and remove it.



3. Install in the reverse order of removal.